



Project Name: _____ Notes/Comments: _____
 Location: _____
 Order Number: _____
 Contractor: _____
 Supplier: _____
 Architect/Engineer: _____

BENEFITS SUMMARY

- Energy saving fan cycling - Title 24 compliant
- Regulates the amount of defrost heat to prevent steaming
- Optional Door Switch with all the necessary time delays
- Off time or electric defrost on pre-defined schedule or custom defrost interval
- Compressor protection - Maximum starts per hour
- Visual and Audible Alarming - High temp/Low temp/Sensors/Door/Power Failure (PF)
- Service Call Saver - Post Defrost Indicator
- Manual defrost
- 1st defrost 2 hrs after start up
- Keyboard Lock Feature

KE2 Low Temp + Defrost

Energy saving refrigeration controller for walk-in freezers and coolers — for new equipment or upgrade of existing refrigeration equipment - **pn 20903**

Description:

Title 24 Compliant insures that evaporator fans, served by a single compressor, and operating without variable capacity controls, will reduce their airflow 40% for at least 75% of the time when compressor is not running.

Specifications

Controller						
Input Voltage:	120V / 208-240V					
Storage Temp:	-40° to 120°F (-40° to 49°C)					
Operating Temp:	-40° to 120°F (-40° to 49°C)					
Display:	4 digit 7-segment LED					
IP Rating:	IP65					
Inputs (4):	2 temperature sensors (KE2 SKU 20199)					
	2 dual purpose (temperature or digital signal inputs)					
Alarm - Visual	Front panel display					
Alarm - Audible	Buzzer					
Alarm - External	Modbus Communication					
Service Call Saver - Post Defrost Indicator*	Display indicates system has just exited defrost					
Outputs: (3) Relays		Normally Open		Normally Closed		
		120V	240V	120V	240V	
	Single Pole	FLA	30A	30A	N/A	12A
	Double Pole	LRA	98A	80A	N/A	24A
	Throw	Resistive	N/A	30A	N/A	30A
	Horsepower	1 hp	2 hp	1/4 hp	1/2 hp	
	Pilot Duty	800VA	720VA	290VA	360VA	
Communication:	RS-485 (Modbus)					
Temperature Sensor						
Sensor Specs:	-60° to 150°F (-51°C to 66°C) moisture resistant package					



***Service Call Saver - Post Defrost Indicator:** To eliminate unwarranted service calls, the controller alerts the user when it is coming out of a defrost cycle using the onboard display. The display alternates between dEF and the actual temperature measured by the air sensor. This continues until the temperature reaches setpoint, or for the amount of time set by dFt (Defrost Time), whichever is shorter.

DIMENSIONS -

Inches

